



Have you ever wished you had just a little bit more speed when trying to catch or drop into a wave?

Or do you wish you could paddle just a little faster when trying to make it past that outside set that's building on the horizon? Well now you can!

WSSM is proud to present an incredible new product that really works- Xtreme Cream!

Proven to reduce friction and drag on your surfboard by 15%, Xtreme Cream is magic for your stick, and "Xtreme-ly" easy to apply. Your board will not only paddle faster,

you'll be taking later drops, experiencing more responsive turns, and if you have an old favorite board that seems to be a bit "slow"... show it some TLC- get some Xtreme Cream on it and we're gonna bet it will quickly become #1 in your quiver again! So next time you're looking over the ledge and wondering if you can actually make that late drop... if you've applied Xtreme Cream to your board... then go-for-it! You've got that extra edge you've always wished for and needed.

APPLYING BLUE GOO ENVIRONMENT-FRIENDLY POWER CLEANER:

For use on: Surfboards, Paddle boards, Ocean Canoes (OC1, OC2, OC4, OC6) and Kayaks, K1, K4, K6 boats, Racing Skulls, Wind surfers, Kite boards, Jet Ski's etc. Use to clean, restore and replenish surface.



1. For surfboards, remove wax build-up with plastic scraper. Remaining wax residue will be removed by Blue Goo.



2. Apply liberally with damp sponge or cloth. Blue Goo will prep the surface for Xtreme Cream by cleaning it of wax, dirt, salt, grime and scuff marks. Blue Goo has a light grit which will clean but will not damage the surface.



3. Rinse off or rub out with soft cloth. For best results, let dry to haze then buff with soft cloth. CAUTION: MAY REMOVE PAINT, CLEAR COAT OR DECALS. TEST IN A SMALL, INCONSPICUOUS SPOT FIRST.

APPLYING XTREME CREAM:

For optimum performance on new boards and rigs; Use Blue Goo Power Cleaner per instructions for a quick wipe down. Rinse and dry. This will prep the surface for the application of Xtreme Cream High Performance Coating

1. Shake bottle.
2. Use damp sponge or soft cloth to apply; squeeze product liberally onto surface and buff in a circular motion. (bottom only for surfboards because Wax will not stick and deck will be too slick to stand on)! Rub in as much as needed to fully coat surface. Xtreme Cream can be applied and rubbed out with a buffer (use lambs wool or soft cloth) for maximum bonding.
3. Cover entire bottom, fins and rails for surfboards or apply to select areas to enhance performance. Can be applied to decks and entire rigs to keep them looking clean and new. Salt water will not stick to Xtreme Cream giving you an easy clean up!

4. Let dry to haze. Air temperature determines the drying time. However, you can wipe off immediately or leave on overnight for best results. The longer it sits, the better Xtreme Cream bonds. Xtreme Cream's exotic polymer starts bonding from the moment it's applied and completely cures in approximately two weeks time.

5. Rub out with soft cloth, making sure all Xtreme Cream residue is removed. Use buffer for optimum shine and performance. Instantly, you'll see and feel the difference!

Xtreme Cream High Performance Bottom Coating will last approximately 2-4 months depending on use. One bottle covers approximately 100 sq. ft.

To Remove Xtreme Creme:

1. Apply Blue Goo product per instructions above.

If you have any questions or concerns regarding these products contact: On It Pro, LLC 4562 Westinghouse St. Unit E, Ventura, Ca 93003 email: info@onitpro.com / www.onitpro.com

